


MLA/KMA Hand Guard Installation

Visit www.jlbillet.com for more information



- 1. Ensure weapon is clear and unloaded
- 2. Apply anti-seize to barrel nut threads
- 3. Torque barrel nut to 45 ft/lbs
- 4. Install hand guard over barrel nut and align with upper
 - There should be a slight drag between the two parts
- 5. Install key seat into slot and align the bolt holes
 - (The radius tab on the key seat should fit into the groove on the barrel nut)
- 6. Install the two 10/32 bolts and torque to 90 in/lbs

The key seat should be tight inside the slot and the hand guard should not rotate.